



This manual is intended primarily for use by professional bicycle mechanics. Users who are not professionally trained for bicycle assembly should not attempt to install the components.

If any part of the information on the manual is unclear to you, do not proceed with the installation. Instead, contact your dealer or a local bicycle shop for their assistance.

Make sure to read all instruction manuals included with the product.

You can find all the manuals and specs on our website <http://ingrid.bike>

MAINTENANCE

This product is not guaranteed against natural wear and deterioration from normal use and aging.

!!! PERIODICALLY CHECK THE TIGHTENING. INCORRECT TIGHTENING CAN CAUSE MALFUNCTIONS OR BREAKAGE

Rev. 1.1 2023/07

MOSCONI s.r.l. | via la Villa 28 zona artigianale Ghilardino 61034 Fossombrone, PU

INSTALLATION

Hand screw the **RING** to preload the crankset until it stops. Make sure there is no play. Tighten the screw to lock the preload ring by a **T10 Torx** screwdriver.

USE THE INCLUDED SPACERS TO COMPLY WITH THE CORRECT DIMENSIONS AS INDICATED ON THE NEXT PAGE


DO NOT USE WAVE WASHERS

AFTER INSTALLATION CHECK THIS DIMENSION

NDS
~11.5 mm



APPLY HIGH QUALITY **LIHIUM+PTFE** GREASE ON THE SPINDLE AND BOTTOM BRACKET




OUR CRANKSET SYSTEM IS DESIGNED WITH AN ASIMMETRY OF +2.5 mm ON DRIVE SIDE

The common **MTB** frames/BB cups are **asymmetrical** and that provides the necessary configuration

The common **ROAD** frames/BB cups are **symmetrical**. In this case add 2.5 mm on the drive side

VERIFY THAT THE FRAME/BB CUPS COMPLIES WITH THE REQUIRED DIMENSIONS FOR OUR SPINDLES


L131 / SRM ROAD



THIS DIMENSION MUST BE REACHED BY THE SUM OF:

- 1 - FRAME BB SHELL WIDTH
- 2 - BEARINGS / BB CUPS
- 3 - SPACERS


L136



THIS DIMENSION MUST BE REACHED BY THE SUM OF:

- 1 - FRAME BB SHELL WIDTH
- 2 - BEARINGS / BB CUPS
- 3 - SPACERS


L141



THIS DIMENSION MUST BE REACHED BY THE SUM OF:

- 1 - FRAME BB SHELL WIDTH
- 2 - BEARINGS / BB CUPS
- 3 - SPACERS

SRM MTB



THIS DIMENSION MUST BE REACHED BY THE SUM OF:

- 1 - FRAME BB SHELL WIDTH
- 2 - BEARINGS / BB CUPS
- 3 - SPACERS